

Flexible Ablators Char Depths LHMEL Test Results

Susan White (NASA)

Vince Qu (San Jose State University)

Wendy Fan, Mairead Stackpoole, Jeremy Thornton (ERC)

Thermal Protection Materials Branch
NASA Ames Research Center
Moffett Field, CA 94035-1000

This work was supported by the following NASA program:
Entry, Descent, and Landing Technology Development

36th Annual Conference on Composites, Materials, and Structures
Cocoa Beach / Cape Canaveral, Florida
January 23-26, 2012



Flexible Ablators Char Depths: *Outline*

- Motivation
- Background
- Approach
- Test Results
- Summary & Conclusions




Flexible Ablators Char Depths: *Motivation*

In 2008, NASA began a 3-year study to establish entry system technologies required to put 40+ metric tons on the surface of Mars *state-of-the-art ~ 1 MT*

Concepts included ablative flexible TPS and dual pulse entry



Fully Margined 23 meter diameter Deployable Heat Shield 80 MT Aero Capture & Entry





Flexible Ablators Char Depths: *Background*


Flexible Ablator Technology Development, FY 10 - 14

- **Determine evaluation criteria** to define successful development
- **Identify promising materials** with flexible matrices / substrates
 - carbon, silica, and polymer based felts / cloths
 - organic / inorganic blended materials
- **Investigate resins, additives, solvents** for flexible composites
- **Utilize lower cost screening tests** to determine viability
 - Aerothermal screening in NASA Ames X-jet plasma torch
 - Thermal screening in radiant environment at Wright-Patterson AFB Laser Hardened Materials Evaluation Laboratory (LHMEL)
 - Aerothermal screening in NASA Johnson TP2 arc heater
 - Fold testing for stowability effects
- **Downselect materials** for further technology (TRL) maturation



Flexible Ablators Char Depths: *Background*

Accurate thermal prediction and analysis requires proper modeling of the char and pyrolysis zones – including reaction kinetics





Flexible Ablators Char Depths: *Background*

Laser Hardened Materials Evaluation Laboratory (LHMEL)


- Reliable, calibrated, and economical laser test facility located at Wright-Patterson AFB and operated by the U.S. Air Force Research Lab
 - Predictable high quality beam, NIST traceable diagnostics
 - High test rate (to 50/day) with purged test box - inert N₂ environment
- LHMEL I is a 15 kW CO₂ laser @ 10.6 micron wavelength
- Newer 10kW IPG Photonics Fiber Laser (1.07 micron) also used
- LHMEL II is a 100 kW CO₂ laser (not part of screening tests)





Flexible Ablators Char Depths: *Background*

- Primary laser used in these screening tests in order to simulate Mars aero capture and entry heating was the 10.6 micron CO₂ laser – LHMEI I
- However, a second laser with a shorter wavelength - 10kW IPG Photonics Fiber Laser at 1.07 micron - was also used
- WHY? - hypersonic entry can produce significant shock layer radiation, with energy concentrated in characteristic wavelengths (e.g. vacuum ultra-violet and near infrared)
- Therefore, 2 lasers with a factor of 10 difference in wavelength used to assess effects from wavelength, with the IPG laser operating near infrared



Example: Laser 1 radiant energy absorbed at or near surface.
Radiant energy from Laser 2 travels further in-depth.



Flexible Ablators Char Depths

- Background
- Motivation
- Approach
- Test Results
- Summary & Conclusions



Flexible Ablators Char Depths: *Objective*

OBJECTIVE: Screening a broad array of flexible ablative TPS materials

- Comparing within classes
- Comparing across classes
- Assessing response to different wavelengths (near infrared vs. mid infrared)

Test Material	Type	Fiber Substrate	Pyrolyzing Component	Characteristics
Morgan-Phenolic FMI-Phenolic	Carbon Phenolic	Carbon Felt	Phenolic	High heat flux/ heat load capability
Morgan-S-T FMI-S-T FMI-S-B FMI-S-T-A1 FMI-S-T-A2 BFFAB Carbon Felt-silicone	Carbon Felt Silicone	Carbon Felt	Silicone resin	Oxidation protection
AFRSI-S-B Refrasil-S-B SIRCA (as Reference)	Glass Fiber w/ Silicone	Silica or Glass Fiber Felt	Silicone resin	Oxidation resistant, efficient at ~ 100 W/cm ²
Carbon/PBI-P-T PBI-S-B	Flex Polybenzimidazole (PBI) fiber	Carbon or PBI Needled Felt	PBI fiber	Exploit high temp pyrolysis of charring fibers
LM3S Silica Felt Blanket LM2Z Zirconia Felt Blanket BFFA Impregnated Nextel	Layered	Carbon or Silica or Zirconia Felt layers	Silicone resin	Thin, tailorable, flexible. Integrate insulation layer by stitching.

KEY: S – silicone P – phenolic F, A* - additive B, T – solvents



Flexible Ablators Char Depths: *Approach*

LHMEL I Test Matrix Dual Pulse for Nominal, High Heating Conditions			
Mission Type	Phase	Max Heat Flux W/cm ²	Duration sec
Nominal	Aero Capture	115	30
	Entry	30	100
High Heating	Aero Capture	450	25
	Entry	115	50

- **Bondline thermocouples used**
- **Exposed area spot size**
 - 2.8" (7.1 cm) diameter for nominal conditions
 - 1.8" (4.6 cm) diameter for higher flux conditions



Flexible Ablators Char Depths: *Approach*

Test matrix of materials

by laser, mission type, and mission phase

Flexible Ablator Screening Test Test Matrix	NOMINAL HEATING			HIGH HEATING	
	Fiber Laser	CO2 Laser		CO2 Laser	
Test Material	Aero Capture	Aero Capture	Entry	Aero Capture	Entry
Morgan-Phenolic				char depth?	char depth?
FMI-Phenolic-F					
FMI-Phenolic					
Morgan-S-T					
FMI-S-T					
FMI-S-B					
FMI-S-T-A1					
FMI-S-T-A2					
BFFAB Carbon Felt-silicone					
AFRSI-S-B					
Refrasil-S-B					
SIRCA (as Reference)					
Carbon/PBI-P-T					char depth?
PBI-S-B					
LM3S Silica Felt Blanket					
LM2Z Zirconia Felt Blanket					
BFFA Impregnated Nextel					

Expectations & Terminology

'Well behaved' or 'good' means


- Maintain structural integrity
- Surviving virgin material
- Recession is relatively even and moderate
- Limited shrinkage, swelling
- No excessive pressure buildup leading to char blowoff
- Stable char: no spall, delamination



Flexible Ablators Char Depths: *Background*

Char and pyrolysis depth measurement from digital cross-section photographs

- Simple, efficient, low cost approach
- Black on black materials pose a challenge for identifying char region
- Many image processing tools available: pixel counting, color tweaking



- Other approaches (in depth thermocouples, XRD, FTIR, x-ray tomography...) are more expensive or appropriate for higher TRL



Flexible Ablators Char Depths

- Background / Motivation

- Approach

- Test Results

- Summary & Conclusions



Carbon fiber reinforced materials

Nominal Aero Capture: 115 W/cm² for 30 sec

Test Material	Type	Fiber Substrate	Pyrolyzing Component	Characteristics
Morgan-Phenolic	Carbon Phenolic	Carbon Felt	Phenolic	High heat flux/ heat load capability
FMI-Phenolic				




Single Pulse 115 W/cm² for 30 seconds



Carbon fiber reinforced materials

Nominal Aero Capture: 115 W/cm² for 30 sec

Test Material	Type	Fiber Substrate	Pyrolyzing Component	Characteristics
Morgan-S-T	Carbon Felt Silicone	Carbon Felt	Silicone resin	Oxidation protection
FMI-S-T				
FMI-S-B				
FMI-S-T-A1				
FMI-S-T-A2				
BFFAB Carbon Felt-silicone				




Single Pulse 115 W/cm² for 30 seconds



Glass fiber reinforced materials

Nominal Aero Capture: 115 W/cm² for 30 sec **Entry: 30 W/cm² for 100 sec**

Test Material	Type	Fiber Substrate	Pyrolyzing Component	Characteristics
AFRSI-S-B	Glass Fiber w/ Silicone	Silica or Glass Fiber Felt	Silicone resin	Oxidation resistant, efficient at ~ 100 W/cm ²
Refrasil-S-B				
SIRCA (as Reference)				




AFRSI / Silicone

Refrasil/ Silicone

SIRCA

Aerocapture (1 pulse)



Entry (dual pulse)


- Limited char growth during Entry (second pulse) simulation
- Silica fiber materials are limited by glass melt to lower heat flux ranges than carbon fiber materials, but gave lower bondline temperatures than carbon




Pyrolyzing fiber reinforced materials

Nominal Aero Capture: 115 W/cm² for 30 sec **Entry:** 30 W/cm² for 100 sec

Test Material	Type	Fiber Substrate	Pyrolyzing Component	Characteristics
Carbon/PBI-P-T PBI-S-B	Flex Polybenzimidazole (PBI) fiber	Carbon or PBI Needled Felt	PBI fiber	Exploit high temp pyrolysis of charring fibers



**PBI with
Silicone Resin**



**Carbon fiber/
PBI fiber blend**



Aerocapture (1 pulse)

Entry (dual pulse)


- PBI decomposes at a higher temperature than phenolic resin, so these materials exploit pyrolysis and charring of the fibers themselves.
- PBI fibers alone shrink upon charring as expected, but the carbon PBI fiber mixture had limited shrinkage due to the carbon fibers




Layered materials

Nominal Aero Capture: 115 W/cm² for 30 sec **Entry: 30 W/cm² for 100 sec**

Test Material	Type	Fiber Substrate	Pyrolyzing Component	Characteristics
LM3S Silica Felt Blanket	Layered	Carbon or Silica or Zirconia Felt layers	Silicone resin	Thin, tailorable, flexible. Integrate insulation layer by stitching.
LM2Z Zirconia Felt Blanket				
BFFA Impregnated Nextel				



Lockheed LM3S layered Silica felt



Lockheed LM2Z layered Zirconia felt



BFFA Boeing Impregnated Nextel

Aerocapture (1 pulse)

- Silica and Zirconia felts were layered, stitched together with ceramic thread
- Nextel fabric loaded with silicone resin
- These materials were relatively thin and gave high bondline temperatures.




Entry (dual pulse)




Carbon fiber reinforced materials

High Heating Aero Capture: 450 W/cm² for 25 sec **Entry:** 115 W/cm² for 50 sec

Test Material	Type	Fiber Substrate	Pyrolyzing Component	Characteristics
Morgan-Phenolic	Carbon Phenolic	Carbon Felt	Phenolic	High heat flux/ heat load capability
FMI-Phenolic				



Single Pulse 450 W/cm² for 25 seconds



First Pulse: 450 W/cm² for 25 seconds
Second Pulse: 115 W/cm² 50 seconds





Carbon fiber reinforced materials

High Heating Aero Capture: 450 W/cm² for 25 sec **Entry:** 115 W/cm² for 50 sec

Test Material	Type	Fiber Substrate	Pyrolyzing Component	Characteristics
Morgan-S-T	Carbon Felt Silicone	Carbon Felt	Silicone resin	Oxidation protection
FMI-S-T				
FMI-S-B				
FMI-S-T-A1				
FMI-S-T-A2				
BFFAB Carbon Felt-silicone				

- Images are of the materials after both pulses
- Silicone resin offers significant oxidation protection
- High-temperature reactions can produce useful SiC, SiOC in the char layer.
- Photos show after dual pulse



raw, untouched image

processed image





First Pulse: Nominal Aerocapture Heating Level

Nominal Heating: CO_2 vs. Fiber lasers

Aero Capture: 115 W/cm^2 for 30 sec

Shorter wavelength NIR Fiber laser resulted in deeper in depth thermal penetration







First Pulse: Nominal Aerocapture Heating Level

Nominal Heating (CO_2 laser only)

Aero Capture: 115 W/cm^2 for 30 sec




Thermal penetration shown by char and pyrolysis zone depths for different materials groupings and modifications





Second Pulse: Nominal Entry Heating







First Pulse: High Option Aerocapture Heating Level

High Heating (CO_2 laser)

Aero Capture: 450 W/cm^2 for 25 sec







Second Pulse: High Option Entry Heating





High Heating (CO_2 laser)

Entry: 115 W/cm^2 for 50 sec









High resolution images :SEM / EDX: Char Layer



Scanning Electron Micrograph (SEM) shows the char zone fibers with a coating, flaking off. Carbon, Oxygen Silicon measurable with EDS – more carbon at the fiber fracture surface. (SEM with backscattered electron detector (BSD) with EDAX energy dispersive X-ray analysis (EDS) system) VQ







SEM / EDS: Pyrolysis Zone



- Carbon, Oxygen Silicon measurable at interface with EDS – mainly Carbon on the fiber surface, dominated by Silicon in the resin



SEM / EDS: Virgin Zone



- Carbon, Oxygen Silicon measurable at interface with EDX – mainly Carbon on the fiber surface, dominated by Silicon in the resin



Flexible Ablators Char Depths

- Background / Motivation
- Approach
- Test Results
- Summary & Conclusions



Key results

- Thicker char depths resulted from laser testing at 1.07 microns versus 10.6 microns, indicating some level of transmission and in-depth absorption at the shorter NIR wavelength.
- This different response - even for carbon fiber materials - impacts
 - material response to shock layer spectral radiation
 - in-depth response to thermal radiation at high temperature gradients.
- Char and pyrolysis zones can be used to plunder test models to extract more information: e.g. distinguish effects of additives, solvents
- Char depths were moderate for the second pulse exposure used to simulate entry after aerocapture, (consistent with bondline temperature and mass loss measurements) that these materials have good potential for dual-pulse aerocapture and entry missions.
- Carbon-fiber reinforced materials had limited char growth under the high heat flux option – so flexible / deployable materials can substitute for rigid TPS materials in that regime. Can we go higher?



Conclusions and future work

- The EDL laser tests were one component of screen tests used to downselect materials to further develop and characterize.
- Char and pyrolysis zone depths give physical evidence of peak temperature reached in depth: The pyrolyzing material acts as a temperature indicator within its characteristic thermal decomposition range. Char depth comparisons are useful:
 - to verify material response models when high fidelity models are available – need to validate density of observed char zone.
 - especially useful to efficiently compare large arrays of novel materials, and/or process and composition modifications.
 - complements quick-turnaround screening using bondline temperatures and mass loss measurements - before characterization or in-depth instrumentation.
- Future work:
 - Compare char depth trends from laser tests to arcjet and other tests. (Note that test conditions are not identical. (Planned)
 - Characterize char and pyrolysis zones with SEM, EDS, FTIR (In progress)
 - Confirm measurements of char density vs. char zones from images for use in high-fidelity thermal model verification. (In progress)
 - Test high-performing flexible ablators to find upper heat flux / heat load limits.



Acknowledgements of Support and Teamwork

This work was supported by the Exploration Technology Development and Demonstration (ETDD) Program.

Thanks to:

- The NASA Ames EDL/TDP Flexible TPS element lead, Robin Beck
- EDL/TDP materials development and evaluation team (Parul Agrawal, Jim Arnold, Al Covington, Matt Gasch, Howard Goldstein, Bernie Laub, Joe Mach, Frank Milos).
- Dave Kinney and Kathy McGuire for simulation results.
- Joe Conley for improving the presentation.
- John Bagford and Dan Seibert from the LHMEEL facility.





Flexible Ablators Char Depths: *Background*

Ablator Modeling


Thermogravimetric analysis (TGA) shows that

- pyrolyzing resin reaction kinetics limit the temp range of decomposition
- carbon felt has minimal effect on the decomposition process






Char density profile:Backup




Carbon Phenolic 1 with a silicone seal coat

- Each slice corresponds to $\sim 1\text{mm}$ thickness
- Felt variability contributes to scatter in density profile
- Virgin density is $\sim 0.23\text{g/cc}$
- **Char density profile: Must correlate visual char depths with density for thermal models**






Char density profile data



Carbon Phenolic 2 with a silicone seal coat

- Each slice corresponds to ~ 1mm thickness
- Virgin density is ~ 0.19g/cc
- Char density profile:
- Must correlate visual char depths with density for thermal models







First Pulse: Nominal Aerocapture Heating Level

Nominal Heating (CO_2 and Fiber lasers)

Aero Capture: 115 W/cm^2 for 30 sec






Second Pulse: Nominal Entry Heating

Nominal Heating (CO² laser)

Entry: 30 W/cm² for 100 sec






First Pulse: High Option Aerocapture Heating Level

High Heating (CO_2 laser)

Aero Capture: 450 W/cm^2 for 25 sec






Second Pulse: High Option Entry Heating

High Heating (CO_2 laser)

Aero Capture: 450 W/cm^2 for 25 sec






First Pulse: Nominal Aerocapture Heating Level

Nominal Heating (CO_2 and Fiber lasers)

Aero Capture: 115 W/cm^2 for 30 sec



Combined char and pyrolysis for materials, modifications, 2 lasers for the nominal test condition

